

# FLIR IR-Monitor

- Monitor Software for the A32X series
- Setup of Analysis ROI's
- Setup of Alarm Settings and I/O functions
- Setup of E-Mail and other Scheduling services



FLIR IR-Monitor is included with all A32X series products. The software is intended to enable the user to set up simple automation and control of up to 9 FLIR A32X cameras simultaneously.

Included on the FLIR SystemTools & Utilities CD.



## FLIR IR-Monitor

- FLIR IR-Monitor, for setup and visualization of up to nine A320 camera's for Stand-alone application and/or online monitoring and control
- Setup of alarms and I/O configuration for Digital out
- Setup of Input sync. For Recording of image(s)
- Draw a Mask to cut out part of image not to be analyzed
- Saving of Images and Image Management
- Setting of Image schedule and E-Mail options
- Synchronies Camera to Internet Time servers



# FLIR IR-Monitor Features

Camera Support	IR-Monitor	
A20/A40/ P-SC65	No	
A325	Yes	
A320	Yes	
AXIS Ethernet Cameras	Yes - <i>the Axis Media Control required</i>	
OS Support		
Windows XP 32-bit	Yes	
Windows Vista 32-bit	Yes	
User Gui and Live view	A320	A325*
Zoom	✓	-
Focus	✓	✓
Freeze	✓	✓
Save	✓	✓
Signal Mode	✓	✓
MPEG4	✓	-
Palettes	✓	✓
NUC	✓	✓
Multi Camera View	✓	✓
Overlay Control On/Off	✓	-
SNTP Synchronisation	✓	-
Object Parameter settings	✓	-
Fever Screening	✓ (Camera Option)	-
Analysis and Result		
Spots (4 spots)	✓	✓
Areas (4 areas)	✓	✓
Differences (4 Diff)	✓	-
Reference Temp	✓	-
Isotherm	✓	-
Alarm Settings	✓	-
Email on Alarm	✓	-
Save Image on Alarm	✓	-
Save and/or Email Image on schedule	✓	-
Audible Alarm	✓	-
Alarm Acknowledgement	✓	-

(\*) The A325 does not have any Internal Analysis functions and the Spots and areas are simulated in IR-Monitor.

Specifications and prices subject to change without notice.  
Copyright © 2009 FLIR Systems. All right reserved including the right of reproduction in whole or in part in any form.

**FLIR Systems, Sweden**  
World Wide Thermography  
Center  
Rinkebyvägen 19 - PO Box 3  
SE-182 11 Danderyd  
Tel: +46 (0)8 753 25 00  
e-mail: sales@flir.se

**FLIR Systems, France**  
Tel: +33 (0)1 41 33 97 97  
e-mail: info@flir.fr

**FLIR Systems, Germany**  
Tel: +49 (0)69 95 00 900  
e-mail: info@flir.de

**FLIR Systems, UK**  
Tel: +44 (0)1732 220 011  
e-mail: sales@flir.uk.com

**FLIR Systems, Italy**  
Tel: +39 02 99 45 10 01  
e-mail: info@flir.it

**FLIR Systems, Belgium**  
Tel: +32 (0)3 287 87 10  
e-mail: info@flir.be



[www.flir.com/thg](http://www.flir.com/thg)